

KT-E02 Model Code Table

(To arrange a hypothetical order according to the brand or its model)

Brand	Model Code	Brand	Model Code
ALPIN	0252, 0253, 1276, 1788	LIANGYU	0233, 0234, 0522, 0525
AUX	0296, 0297, 0452-0456	LITTLE DUCK	0532, 0533, 0535
BOERKA	0383-0386, 0434, 0435, 1272	LOREN-SEBO	0254, 1274, 1789, 2291
CARRIER	0203, 0204, 0456, 0563, 0564	MACQUAY	0231, 0232, 1271, 2292
CHANGHONG	0288, 0290, 0291, 0292, 0382	MICOM	0415, 0416, 2463, 2468
CHIGO	0069-0072, 1278, 1779	MIDEA	0008-0015, 0481, 0482, 0561, 1773
CHOFU	0184, 1207, 1711, 1723, 2435	mitsubishi	0100-0108, 0470-0473
CHUNLAN	0379-0381, 0457, 0458	NORITZ	0430, 0431, 1269, 2276
CORONA	0155, 0441, 1275, 2286	PANASONIC	0138-0154, 0483-0489
CONROWA	0374, 0376, 1270	PANDA	0379, 0380, 1279, 2295
DAEWOO	0200, 0208, 0406, 0407	PHILCO	0213-0215, 0528, 0529
DAIKIN	0171-0179, 0567	PROTON	0422, 0423, 2427, 2462
DOCTOR	0197, 0438, 2430, 2464	RAYBO	0366, 0367, 1285, 2294
DONGBAO	0361, 0362, 1273	ROWA	0353, 0354, 0453, 2454
DONGXINBAO	0417, 0418, 2460, 2461	SACON	0331, 0450, 0455, 1266
Electrolux	0216-0220, 0565	SAMSUNG	0182, 0183, 0523, 0524
FEDDERS	0169, 0463, 2465	SANYO	0723-0733, 0569, 0570
FRETECH	0161, 0480, 1713, 2445, 2466	SASUKI	0255, 0256, 0519, 0520
FUJITSU	0127-0137, 0464-0469	SHANGLING	0371, 0372, 1276, 2296
FUNAI	0437, 1277, 1957, 2309	SHANXING	0369, 1275, 2279, 2280
GALANZ	0372, 0373, 0459, 0460	SHARP	0093-0096, 0158-0163, 0489-0493
GLEE	0398, 0399, 1288, 2232	SHENGFENG	0355, 0356, 1287, 2297
GOLDSTAR	0160, 0161, 0512, 0513	SHINCO	0217, 0218, 1267, 2277
GREE	0001-0007, 0515, 0516	SHUANGLU	0357, 0358, 0452, 0459
HAIER	0268-0272, 0451, 0474-0479	SONGGE	0427, 0428, 2419, 2420
HISENSE	0122, 0123, 0125, 0126	SOVA	0332, 0333, 1266, 2271
HITACHI	0111, 0112, 0117, 0118	SUMMER	0425, 0426, 2421, 2422
HUABAO	0339, 0343, 1280, 2287	SUNDURG	0363, 0364, 1284, 2274
HUAKE	0403, 0404, 1284, 2239	SWAN	0306, 0307, 0439, 0440
HUAMEI	0409, 0410, 2236	TADIRAN	0257, 0258, 2431, 2469
HUALING	0326, 0327, 0450, 0455	TATUNG	0113, 0114, 1264, 2272
HUIFENG	0370, 0371, 0453, 0454	TCL	0373, 0374, 1273, 2282
HYUNDAI	0209-0212, 0526, 0527	TECO	0259, 0260, 1277, 2278
JDC	0377, 0378, 0481, 0482	TIANDI	0305, 0306, 1288, 2285
JIANGNAN	0389, 0390, 1282, 2288	TOSHIBA	0109, 0110, 0484, 0485
JINDA	0308, 0309, 1286, 2293	TRANE	0227, 0228, 1272, 2275
JINSONG	0387, 1281, 2289, 2290	UNI-AIR	0229, 0230, 0521, 0522
JOHNSON	0248-0251, 0517, 0518	WEILI	0419, 0420, 1268, 2273
KANGLI	0375, 0391, 0392, 1283	WHIRLPOOL	0164-0168, 0494, 0495
KELONG	0210, 0211, 0412, 0413	WINIA	0194, 0195, 0510, 0511
KINTAR	0221, 0222, 0523, 0524	XILENG	0411, 0412, 2423, 2424
KONKA	0236-0238, 0520, 0521	YANGZI(YAIR)	0401, 0402, 2415, 2416
LG	0198, 0199, 0514, 0511	YINYAN	0223-0226, 0566, 0567
		YUETU	0405, 0406, 2417, 2418
		ZHIYIN	0393, 0394, 1286, 2298



MADE IN CHINA

NO:KG-02E2-24V1



Patented product, counterfeits will investigate cost liability

Blind friends also can use

Product Description

Thank you for choosing this superior remote control. It is greatest choice of your dream to go for choices as you wish.

KT-E02 One-key universal A/C remote control is a high-tech product with elegant appearance (modern flowing streamlined by curve design). Perfect function of kt-e02, you could enjoy wonderful life by this best & handy far away remote control such as one key function get you easy & quickly to search for exact temperature, you could use it as a thermometer. Set it yet & read the room temperature.

KT-E02 one-key universal remote is a 4000 in 1-type, could use for both of world-wide famous A/C and old ones. Insert two new quality batteries turn it the world-light Please read this manual well and your remote for your handy before using and hope that it will help for you to use this remote.

Setting of remote

Put slot cover of remote control down, put 2s AAA(UM-4, R03) batteries as per you indicated on the battery cabin. And set up your remote with one of the following three methods.

1. Model seeking(one time)

Find out the required model for remote control, refer to model table seeking groups of numbers, for example if your A/C is Midea group, it is number 8, then press model code as designation of this remote. Set searching or "TEMP" key, and adjust by "SELECT" with shift, found correct until LCD display except code " " and " ", the corresponded model appears. Then press "ENTER" key to confirm by three different methods of your selection, if they work well, you could use it normally.

2. Auto-search code seeking

If you do not know what brand of your air conditioner, or if your brand is not found from the model table, if you could try auto-search code.

Put the slot cover of battery as per you indicated on the battery cabinet, button up the "SEARCH" 5 seconds and release, the remote control is entering to auto-search status. launch the signal continuously, the code is flashing in LCD window. These are the functions as per new model, waiting at this time, until the remote control with transmission. Please keep waiting, it will stop quickly at you slide to the button of another key, you would stop this correct code.

3. If the remote aim at your air conditioner again, press "one-key" non-stop" button except reset of mode functions. Otherwise starting again use above methods.

Function indication

1. One-key nonstop function

After setting deatate, whether in summer or winter, when you want to use air conditioner,press on "one-key" non-stop button except the " " mode", remote will adjust the room in a summer or winter according to the current temperature.

Function Indication

Summer the tempogxet (Set the temp) to 26 °C in winter, the temperature will be set in 20 °C.(Cool and not cold),saving electric. (The wind up/down direction of the thermometer, you could adjust by keys "▲" or "▼". Of course, the measured data is the same using this remote at different time).

1. Clock set operate:

- Press the "CLOCK" with shift, it is blinking.
- Press the "TIME" ▲ or ▼, adjusting the current time.
- Finish by "CLOCK" will stop blinking. ②-③ is optional, the time setting dispoable if you do not operate "②-CLOCK" button, it can operate automatically about 5 seconds

2. Timer off setting of remote control:

- Timed off, you could set it off while operating on your air conditioner.
- Press "TMR. OFF" key, the off time is blinking (10-120 seconds the Flash) ..
- Press "TEMP" ▲ or ▼, have to regulated time. Pressing once is one minute, Press and hold it 1.5s will increase 10 seconds quickly.
- The setting state a d will appr 5 seconds. The LCD displays current time and Countdown. Now working.

4. Thermometer function:

Show the indoor temperature, it can remain displays the room temperature, can operate as thermometer.

Attention

- If it is not used for a long time, remove the battery to avoid leakage fluid of the battery to damage the machine. When the LCD looks dim, please change the new battery. And put the slot cover must be used before hand. The batteries are available in supermarkets or many stores with electrical appliances.
- Please aim the LCD in a instead to blow to it, it is invalid (or no signal). "Enter" keys, you can find the code will be showed in LCD. After 5 seconds it rets to current mode.
- Check it carefully that there is no remote position be remotee control or air-conductor receiver from the most distant 7mtr. Because the operation influence or other reason, the appropriate moving in time for remote could never remote control.
- The manufacturer keeps right to change the parameters and functions of product.

Technical Parameters

Deservable distance: Large 8 met more (according to the received)
Battery model: Battery AAA(UM-4, R03)x2
Dimension: L 165mm×W55mm×H 25mm
Weight(approx) : 100g (No batteries)

● The design and specification of this instrument (discrepancy, Any alternation on the design and facult) will not be further notified.